





## Energizer Solar Peak 3000 Mobile Application

**User Manual** 

## 1. Software Download


Search for Smart Life within your mobile devices app store, or scan the QR codes below to download and install.





## 2. Adding Device


Select the + icon located at the top right of your interface and select Add Device.




## 3. Enable Bluetooth

Follow the on screen prompts to set **Enable Nearby Devices** permission and **Enable Bluetooth** so you can connect WiFi devices.










## 4. Connecting Device to WiFi


At the main interface, your device information will automatically appear. If it doesn't appear, go to Add Device, then find the device to connect and select Add. Please fill in the WiFi information to connect the device.





#### Instructions to manually connect device.





## 5. Successful Connection on Device

If the WiFi icon on the LCD screen is always on, this means the connection is successful.



If your are unsure if the device has already been paired, you can resit the WiFi pairing by pressing the LCD Button and ON/OFF Button at the same time. If successfully done, the WiFi icon will flash on the LCD Screen.



#### NOTE:

Once the WiFi is successfully connected, you will be able to use the Energizer Solar Portables App to control the device via Bluetooth without needing to connect to the WiFi.

If there is no WiFi available when connecting, you can also use your mobile device as a HotSpot to complete the WiFi connection process.

## 6. Parameter Set


#### **View Device Information.**

After your have successfully connected to the device, the device will appear on the main interface.





### 7. Device Interface on Dashboard







Energizer Solar 2500 Expansion Batteries are sold separately.

## 8. Device Parameters Settings

On the dashboard interface, click the **Setting** icon located at the top right of the screen.






#### **Charge & Discharge Limits**

This is the charge & discharge limits. The default settings are set to 0% and 100%. If you wish to change the limits, this means the State of Charge (SOC) must be between the values you set to charge and discharge properly.



#### **AC Charging Power Limits**

This is the AC charging power limits. The default setting is set to 100%. If you wish to change the limits, this means the AC charging power is limited to the value you set of the maximum power.



#### **Car Charging Current Limits**

This is the car charging limits. The default setting is set to 8A.You are able to change the charging current based on your vehicle requirements.




#### **Inverter Output Frequency**


This is the inverter output frequency, which provides two options of 50Hz and 60Hz.



#### **Key Sound**

This is the key sounds switch. Toggle between ON and OFF.





#### **Restore Settings**

This is to restore the device to its factory settings. Once prompted, select Confirm to restore settings.




#### **Fast Charging Switch**

Fast charging switch refers to the switch of fast and slow charge mode of the mains. The switch is turned off by default. After it is turned on, the system enters the mains fast charge mode.




#### Micro Inverter Mode

In micro-inverter mode, two time periods can be set to release the energy stored in the 3000W Power Station to the grid for use by household loads to reduce electricity bills.



#### **Device Standby Time**

Device standby time refers to the countdown to turn off the device when the AC output switch is off and there is no charging and discharging. The factory default value is 2 hours.




#### **INV Standby Time**

INV standby time refers to the AC output switch is turned on, there is no AC output, and it automatically shuts down when it reaches the set time. The factory default value is 1 hour.



#### **Screen Timeout**

Screen timeout refers to the time when the screen automatically turns off after the touch screen operation is finished. The factory default value is 5 minutes.




#### **Equipment Specification**

This is the equipment specification, you can view the device specification information here.



#### **Temperature Unit**

This is the battery temperature unit, you can choose Celsius or Fahrenheit.



#### More

You can select 'More' to view more features.





# Discover the Energizer Solar Portable Power range!

The Energizer Solar Portable Power range offers reliable and sustainable charging solutions for all your electronic devices. Harnessing the power of the sun, these portable power products provide a convenient and eco-friendly way to stay connected on the go. With advanced technologies and durable construction, Energizer Solar Portable Power ensures high performance and long-lasting power supply in any outdoor adventure or emergency situation.





888 Prospect Street, Suite 200 La Jolla California 92037 +1 424 254 5344

The Black Church, St Mary's Place Dublin D07 P4AX, Ireland +353 1 254 8222

Level 35, 477 Collins St, Melbourne Victoria 3000, Australia +61 1300 757 827



© 2024 Energizer. Energizer and certain graphic designs are trademarks of Energizer Brands, LLC and related subsidiaries and are used under license by 8 Star Energy Pty Ltd. All other brand names are trademarks of their respective owners. Neither 8 Star Energy Pty Ltd nor Energizer Brands is affiliated with the respective owners of their trademarks.